



Instructions

Non-Ratchet Type : Remove the closed lock to open the handles.

Ratchet Type : Squeeze the handles until it stops to open the handles.

1. Cutting modular cable :

Place the single-bladed side of the tool's cutter facing you and cut the modular cable to the desired length. Make sure to cut the ends of the cord straight across, not diagonally.

2. Stripping modular cable :

2a. Insert 4P/6P cable into the two-bladed side of the tool's stripper until it touches the stop guide.

2b. Insert 8P/10P cable into the two-bladed side of the tool's stripper and let it extend a little past the lower cut blade.

3. Squeeze handles until it stops, cable must be kept perpendicular and then pull from the tool.

4. Remove the outer jacket, insert the stripped cable into the plug and be sure the left wire at one end matches the right wire at the other end.

5. Place modular plug with cable into the tool's holder. Be sure the stripped wire is between the tab and gold contacts. Squeeze handles until it stops.

6. Remove the crimped plug from the tool.

7. For stripping UTP/STP round cable, please use GKTYA for good result.

FOR CRIMPING MODULAR PLUG

KKTRS

8P8C/RJ-45, 6P6C/RJ-12, 6P4C/RJ-11 PLUGS, W/RATCHET