

User's Manual

10/100/1000Base-T to 1000Base-X
PoE PSE GbE Media Converter

Release 1.0

The information in this document is subject to change without notice. Unless the explicit written permission of Manufactory, this document in whole or in part shall not be replicated or modified or amended or transmitted, in any form, or by any means manual, electric, electronic, electromagnetic, mechanical, optical or otherwise for any purpose.

DURATION OF HARDWARE WARRANTY

HARDWARE: In accordance with the provisions described under, Manufactory warrants its hardware products (hereinafter referred to as "Product") specified herein to be for a period of twelve (12) months / 3 years (Industrial) from the date of shipment.

Should a Product fail to perform during the effective warranty period as described above, Manufactory shall replace the defective Product or part, or delivering a functionally equivalent Product or part in receipt of customer's request, provided that the customer complies with the return material authorization (RMA) procedures and returns all defective Product prior to installation of the replacements to Manufactory.

All defective Products must be returned to Manufactory with issuance of a Return Material Authorization number (RMA number) assigned to the reseller from whom the end customer originally purchased the Product. The reseller is responsible for ensuring the shipments are insured, with the transportation charges prepaid and the RMA number clearly marked on the outside of the package. Manufactory will not accept collect shipments or those returned without an RMA number.

Manufactory shall not be responsible for any software, firmware, information or memory data contained in, stored on or integrated with any Product returned to Manufactory pursuant to any warranty.

EXCLUSIONS. The warranty as mentioned above does not apply to the following conditions, in Manufactory's judgment, it contains (1) customer does not comply with the manual instructions offered by Manufactory in installation, operation, repair or maintenance, (2) Product fails due to damage from unusual external or electrical stress, shipment, storage, accident, abuse or misuse, (3) Product is used in an extra hazardous environment or activities, (4) any serial number on the Product has been removed or defaced, (5) this warranty will be of no effect if the repair is via anyone other than Manufactory or the approved agents, or (6) in the event of any failures or delays by either party hereto in the performance of all or any part of this agreement due to acts of God, war, riot, insurrection, national emergency, strike, embargo, storm, earthquake, or other natural forces, or by the acts of anyone not a party to this agreement, or by the inability to secure materials or transportation, then the party so affected shall be executed from any further performance for a period of time after the occurrence as may reasonably be necessary to remedy the effects of that occurrence, but in no event more than sixty (60) days. If any of the stated events should occur, Party A shall promptly notify Party B in writing as soon as commercially practicable, but in no event more than twenty (20) business days and provide documentation evidencing such occurrence. In no event shall the maximum liability of Manufactory under this warranty exceed the purchase price of the Product covered by this warranty.

DISCLAIMER. EXCEPT AS SPECIFICALLY PROVIDED ABOVE AS REQUIRED "AS IS" AND THE WARRANTIES AND REMEDIES STATED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS, ORAL OR WRITTEN, EXPRESS OR IMPLIED. ANY AND ALL OTHER WARRANTIES, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR THIRD PARTY RIGHTS ARE EXPRESSLY EXCLUDED.

MANUFACTORY SOFTWARE LICENSE AGREEMENT

NOTICE: Please carefully read this Software License Agreement (hereinafter referred to as this "Agreement") before copying or using the accompanying software or installing the hardware unit with pre-enabled software or firmware (each of which is referred to as "Software" in this Agreement). BY COPYING OR USING THE SOFTWARE, YOU ACCEPT ALL OF THE PROVISIONS AND CONDITIONS OF THIS AGREEMENT. THE PROVISIONS EXPRESSED IN THIS AGREEMENT ARE THE ONLY PROVISION UNDER WHICH MANUFACTORY WILL PERMIT YOU TO USE THE SOFTWARE. If you do not accept these provisions and conditions, please immediately return the unused software, manual and the related product. Written approval is NOT a prerequisite to the validity or enforceability of this Agreement and no solicitation of any such written approval by or on behalf of Manufactory shall be deemed as an inference to the contrary.

LICENSE GRANT. The end user (hereinafter referred to as "Licensee") of the Software is granted a personal, non-sublicensable, nonexclusive, nontransferable license by Manufactory : (1) To use the Manufactory's software ("Software") in object code form solely on a single central processing unit owned or leased by Licensee or otherwise embedded in the equipment offered by Manufactory. (2) To copy the Software only for backup purposes in support of authorized use of the Software. (3) To use and copy the documentation related to the Software solely in support of authorized use of the Software by Licensee. The License applies to the Software only except other Manufactory's software or hardware products. Without the prior written consent of Manufactory, Licensee has no right to receive any source code or design documentation with respect to the Software.

RESTRICTIONS ON USE; RESERVATION OF RIGHTS. The Software and related documentation are protected under copyright laws. Manufactory and/or its licensors retain all title and ownership in both the Software and its related documentation, including any revisions made by Manufactory. The copyright notice must be reproduced and included with any copy of any portion of the Software or related documentation. Except as expressly authorized above, Licensee shall not copy or transfer the Software or related documentation, in whole or in part. Licensee also shall not modify, translate, decompile, disassemble, use for any competitive analysis, reverse compile or reverse assemble all or any portion of the Software, related documentation or any copy. The Software and related documentation embody Manufactory's confidential and proprietary intellectual property. Licensee is not allowed to disclose the Software, or any information about the operation, design, performance or implementation of the Software and related documentation that is confidential to Manufactory to any third party. Software and related documentation may be delivered to you subject to export authorization required by governments of Taiwan and other countries. You agree that you will not export or re-export any Software or related documentation without the proper export licenses required by the governments of affected countries.

LIMITED SOFTWARE WARRANTY. Manufactory warrants that any media on which the Software is recorded will be free from defects in materials under normal use for a period of twelve (12) months/ 3 years(industrial) from date of shipment. If a defect in any such media should occur during the effective warranty period, the media may be returned to Manufactory, then Manufactory will replace the media. Manufactory shall not be responsible for the replacement of media if the failure of the media results from accident, abuse or misapplication of the media.

EXCLUSIONS. The warranty as mentioned above does not apply to the Software, which (1) customer does not comply with the manual instructions offered by Manufactory in installation, operation, or maintenance, (2) Product fails due to damage from unusual external or electrical stress, shipment, storage, accident, abuse or misuse, (3) Product is used in an extra hazardous environment or activities, (4) any serial number on the Product has been removed or defaced, or (5) this warranty will be of no effect if the repair is via anyone other than Manufactory or the authorized agents. The maximum liability of Manufactory under this warranty is confined to the purchase price of the Product covered by this warranty.

DISCLAIMER. EXCEPT AS PROVIDED ABOVE, THE SOFTWARE IS PROVIDED "AS IS " AND MANUFACTORY AND ITS LICENSORS MAKE NO WARRANTIES, EXPRESS OR IMPLIED, WITH REPECT TO THE SOFTWARE AND DOCUMENTAITON. MANUFACTORY AND ITS LICENSORS DISCLAIM ALL OTHER WARRANTIES, INCLUSIVE OF WITHOUT LIMITATION, IMPLIED WARRANTIES OR MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. FURTHER, MANUFACTORY DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATIONS REGARDING THE USE, OR THE RESULTS OF THE USE, OF THE SOFTWARE OR RELATED WRITTEN DOCUMENTAITON IN TERMS OF CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE.

CONSEQUENTIAL DAMAGES. IN NO EVENT SHALL MANUFACTORY OR ITS AUTHORIZED RESELLER BE LIABLE TO LICENSEE OR ANY THIRD PARTY FOR (A) ANY MATTER BEYOND ITS REASONABLE CONTROL OR (B) ANY CONSEQUENTIAL, SPECIAL, INDIRECT OR INCIDENTAL DAMAGES ARISING OUT OF THIS LICENSE OR USE OF THE SOFTWARE PROVIDED BY MANUFACTORY. EVEN IF MANUFACTORY HAS BEEN NOTIFIED OF THE POSSIBILITY OF SUCH DAMAGES IN ADVANCE. IN NO EVENT SHALL THE LIABILITY OF MANUFACTORY IN CONNECTION WITH THE SOFTWARE OR THIS AGREEMENT EXCEED THE PRICE PAID TO MANUFACTORY FOR THE LICENSE.

TERM AND TERMINATION. The License is effective until terminated; however, all of the restrictions in regard to Manufactory's copyright in the Software and related documentation will cease being effective at the date of expiration; Notwithstanding the termination or expiration of the term of this agreement, it is acknowledged and agreed that those obligations relating to use and disclosure of Manufactory's confidential information shall survive. Licensee may terminate this License at any time by destroying the software together with all copies thereof. This License will be immediately terminated if Licensee fails to comply with any term and condition of the Agreement. Upon any termination of this License for any reason, Licensee shall discontinue to use the Software and shall destroy or return all copies of the Software and the related documentation.

GENERAL. This License shall be governed by and construed pursuant to the laws of Taiwan. If any portion hereof is held to be invalid or unenforceable, the remaining provisions of this License shall remain in full force and effect. Neither the License nor this Agreement is assignable or transferable by Licensee without Manufactory's prior written consent; any attempt to do so shall be void. This License constitutes the entire License between the parties with respect to the use of the Software.

LICENSEE ACKNOWLEDGES THAT LICENSEE HAS READ THIS AGREEMENT, UNDERSTANDS IT, AND AGREES TO BE BOUND BY ITS TERMS AND CONDITIONS. LICENSEE FURTHER AGREES THAT THIS AGREEMENT IS THE ENTIRE AND EXCLUSIVE AGREEMENT BETWEEN MANUFACTORY AND LICENSEE.

Table of Contents

1. OVERVIEW	1
2. MODEL DESCRIPTION	1
3. CHECKLIST	2
4. INSTALLING THE CONVERTER	2
5. WDM SINGLE FIBER MODEL	5
6. LINK FAULT PASS THROUGH	6
7. LED DESCRIPTION	8
8. DIP SWITCH AND RESET BUTTON	8
9. CABLE CONNECTION PARAMETER	9
10. POE PSE TP-FIBER TECHNICAL SPECIFICATIONS	9

Caution

Circuit devices are sensitive to static electricity, which can damage their delicate electronics. Dry weather conditions or walking across a carpeted floor may cause you to acquire a static electrical charge.

To protect your device, always:

- Touch the metal chassis of your computer to ground the static electrical charge before you pick up the circuit device.
- Pick up the device by holding it on the left and right edges only.

Electronic Emission Notices

Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a class A computing device pursuant to Subpart J of part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment.

European Community (CE) Electromagnetic Compatibility Directive

This equipment has been tested and found to comply with the protection requirements of European Emission Standard EN55022/EN60555-2 and the Generic European Immunity Standard EN50082-1.

EMC:	EN55022(1988)/CISPR-22(1985)	class A
	EN60555-2(1995)	class A
	EN60555-3	
	IEC1000-4-2(1995)	4K V CD, 8KV, AD
	IEC1000-4-3(1995)	3V/m
	IEC1000-4-4(1995)	1KV – (power line), 0.5KV – (signal line)

1. Overview

10/100/1000Base-T to 1000Base-SX/LX (LC) IEEE802.3z/ab GbE media converter, which allows two types of network segments to be connected easily and inexpensively. Complied with IEEE802.3af Power Over Ethernet standard, this AC powered PoE media converter is a Power Sourcing Equipment (PSE) which combines data received over a TP link with –48VDC power, providing power to IEEE802.3af powered device (PD) over the existing CAT5 UTP cable. The converter includes a PD signature sensing and power monitoring features. Other features include over-current protection, under-current detection and fault protection input. The LFP (Link Fault Pass-through) allows the media converter to monitor both the fiber and copper RX ports for loss of signal. In case of a loss of RX signal on one media port, the converter will automatically disable the TX signal to the other media port, thus passing through the link fault. FEF (Far End Fault) enables the converter to stop sending link pulse to the link partner once a loss of the fiber RX signal is encountered. Then the link partner will synchronously stop sending data. FEF prevents loss of valuable data transmitted over invalid link. Combining LFP and FEF troubleshooting features of the converter, both end devices can be notified of a loss of fiber link.

2. Model Description

Model	Description
PoE PSE TP-Fiber SC	10/100/1000Base-T to 1000Base-SX PoE PSE GbE converter, MM SC
PoE PSE TP-Fiber SC.Sxx	10/100/1000Base-T to 1000Base-LX PoE PSE GbE converter, SM SC 10/30/50km
PoE PSE TP-Fiber BSx.Sxx	10/100/1000Base-T to 1000Base-LX PoE PSE GbE converter, SM Bidi SC 10/20km, 1310nm/1550nm
PoE PSE TP-Fiber LC	10/100/1000Base-T to 1000Base-SX PoE PSE GbE converter, MM LC
PoE PSE TP-Fiber LC.Sxx	10/100/1000Base-T to 1000Base-LX PoE PSE GbE converter, SM LC 10/30/50km

The other spec. is available upon request

3. Checklist

Before you start installing the Converter, verify that the package contains the following:

- The PoE PSE TP-Fiber Converter
- AC Power Cord
- This User's Manual

Please notify your sales representative immediately if any of the aforementioned items is missing or damaged.

4. Installing the Converter

PSE TP-Fiber Converter with Powered Device (PD)

- ⇒ Connect the PSE media converter to an AC power source
- ⇒ Install the TP media cable to the IEEE 802.3af PD converter (See Fig. 2)

Note: It can work as a pure converter that connects to the non-PoE converter.

- ⇒ Install the media cable for network connection

Warning:

- ⇒ Verify that the AC input conforms to your country AC power requirement and then insert the power plug
- ⇒ Ensure that the power of PSE device is turned on
- ⇒ Install the media cable for network connection

TP Port	10/100Base-TX Auto-Negotiation Auto-MDIX flow control for Full-Duplex backpressure for Half-Duplex
	1000Base-TX Auto-Negotiation mode Auto-MDIX only for Auto-Negotiation flow control for Full-Duplex only
Fiber Port	1000Base-SX/LX (SC/LC) with NWay flow control Link partner must be 1000FDX with NWay flow control



Fig. 1 The View of PoE PSE Media Converter




Fig. 2 Connection among PSE PoE Converter, Fiber and TP Cables




Fig. 3 PSE to PD or PoE Splitter




Fig. 4 PoE PSE Media Converter Front Panel (SFP)




Fig. 4 PoE PSE Media Converter Front Panel (SC)




Fig. 5 PoE PSE Media Converter Rear Panel




Fig. 6 Endpoint PSE RJ-45 Male Connector

Note:

IEEE802.3af assigns pairs on the RJ-45 connector and Cat.5 cable of Endpoint PSE.

Endpoint : -48V via TP pin 1, 2, 3, 6

5. WDM Single Fiber Model

The TP-Fiber converter is specially designed with an optic Wavelength Division Multiplexing (WDM) model that can transport bi-directional full duplex signal over a single fiber simultaneously.

Single Fiber Model	TX, RX Wavelength	
1310nm Single-Mode 10Km * 20Km models are option	TX (Transmit)	1310nm
	RX (Receive)	1550nm
1550nm Single-Mode 10Km * 20Km models are option	TX (Transmit)	1550nm
	RX (Receive)	1310nm

Note:

The 1310nm and 1550nm models must be installed in pairs, i.e., install 1310nm model at one end and 1550nm model at the other one.




Fig.7 PoE PSE WDM Single Fiber Converter Front Panel




Fig. 8 Power from PSE to PD

6. Link Fault Pass Through

The Converter model of LFP (link fault pass through) in TX/FX converter application is controlled by the software and instantly take effect. Link status on one port is propagated to the other port to notice the remote nodes. If TP port is unplugged, this converter stops transmission on fiber port. This causes the remote fiber node link to fail. LED shows the link failure on both TP and fiber ports. If fiber link fails, this converter restarts auto-negotiation on TP port but always stays in the link failure state. This causes the remote TP node link to fail. LED also shows the link failure on both TP and fiber ports. Refer to Fig. 9 shown below for the normal status when the link succeeds. Also refer to Fig. 10 and Fig. 11 for the erroneous status when TP Cable A, Fiber Cable B or Fiber Cable C fails to connect.

Note: Link fault pass through (LFP) function only takes effect as S1-Bit2 (see Fig. 15) is enabled. Disabled S1-Bit2 will turn this media converter into a general one.




Fig. 9 Normal status via LFP converter




Fig. 10 The status as TP Cable A or D is broken




Fig. 11 The status as Fiber Cable B or C is broken




Fig. 12 Normal status via LFP converter




Fig. 13 The status as TP Cable A is broken




Fig. 14 The status as Fiber Cable B or C is broken

Note : ●	Indicates LNK/ACT LED Lit
○	Indicates LNK/ACT LED Off

Notice: The LFP (Link Fault Pass Through) function can work with different link partners (for Example: Fiber port on Switch). It does not need both two converters with the same model in pairs.

7. LED Description

LED	Color	Function
FX LNK/ACT	Green	Lit when fiber connection is good Blinks when fiber data is present
TP LNK/ACT	Green	Lit when TP connection is good Blinks when TP data is present
TP SPD	Green Amber	Green Lit when TP speed is 1000Mbps Amber Lit when TP speed is 100Mbps Off when TP speed is 10Mbps
PWR	Green	Lit when +5V power is coming up
PoE PSE-TP	Green	Lit when PoE feeding power is active
	Red	Lit when PoE feeding power is disrupted (In case of overtemperature/overcurrent)
4W	Green	Light when PD Class Type is Class 1
7W	Green	Light when PD Class Type is Class 2
15.4W	Green	Light when PD Class Type is Class 0 or 3

8. DIP Switch and Reset Button




Fig. 15 Reset button and S1—Bit 1, 2, 3 Configuration and Setting

Reset : Once S1-1, S1-2 is changed, please press this button to have the setting taken effect.

- S1-1 Bridge mode : Cut through (default) or Normal
 S1-2 LFP : LFP enabled(default) or disabled
 S1-3 PoE ON/OFF : Enable(default) or disable

Note:

- S1-1 : Cut through mode support jumbo frame size max. up to 9216Bytes. Normal mode max. frame size up to 2048 Bytes
- S1-3 : Must be set to PoE ON while power supplies to PD.

9. Cable Connection Parameter

1000Base-SX/LX network only support full-duplex mode. The Switch-based Media Converter breaks up TP and Fiber segments' collision domain to extend the cabling distance.

- **TP Cable Limitations:** Cat. 5 and up to 100m
- **Converter Fiber Cable Limitations:**

Mode	Multi-Mode Fiber 62.5/125 μ m		Multi-Mode Fiber 50/125 μ m	
	Bandwidth MHz-Km	Distance	Bandwidth MHz-Km	Distance
1000SX (LC) 850nm	160	220m	400	500m
	200	275m	500	550m
1000LX (LC) 1310nm/ 1550nm	Single-Mode Fiber 9/125 μ m Single-Mode transceiver 1310nm: 10/30Km Single-Mode transceiver 1550nm: 50Km			

Single Fiber Model	TX, RX Wavelength	
1310nm Single-Mode 10Km * 20Km models are option	TX (Transmit)	1310nm
	RX (Receive)	1550nm
1550nm Single-Mode 10Km * 20Km models are option	TX (Transmit)	1550nm
	RX (Receive)	1310nm

Note:

The 1310nm and 1550nm models must be installed in pairs, i.e., install 1310nm model at one end and 1550nm model at the other one.

10. PoE PSE TP-Fiber Technical Specifications

- **Standards** : IEEE802.3u 10/100Base-TX, 100Base-FX
IEEE802.3z/ab 1000Base-T
IEEE802.3af Power over Ethernet
- **UTP Cable** : Cat. 5 cable and up to 100m
- **Fiber Cable** : 50/125, 62.5/125 or 100/140 μ m multi-mode
8.3/125, 8.7/125, 9/125 or 10/125 μ m single-mode
- **PSE Power Feeding Supports** :
"Endpoint" via TP pin 1, 2, 3, 6
- **LED Indicators** :
POWER, PoE, TP LNK/ACT, SPD, FX LNK/ACT, 4W, 7W, 15.4W
- **Data Transfer Rate** :

Speed	Forwarding Rate
1000Mbps	148,8000 PPS
100Mbps	148,800 PPS
10Mbps	14,880 PPS

- **Flow Control** : IEEE802.3x compliant for full duplex
Backpressure flow control for half duplex
- **Power Requirement** :
AC Line: 100-240V 50-60Hz
- **Power Consumption** : 24W
- **Ambient Temperature** : 0° to 50°C
- **Humidity** : 5% to 90%
- **Dimensions** : 40(H) × 158(W) × 133(D) mm
- **Complies with FCC Part 15 Class A and CE Mark**

Note: For connecting this device to Router, Bridge or Switch, please refer to the corresponding device's Technical Manual.